

ORANIER


Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois

1.

Brennstoffwähler

Fuel selector / Sélection du combustion




Braunkohle
Lignite briquettes
Briquettes lignite

2.

Sekundärluftregler Start


Secondary air control / Régulateur d'air secondaire



3.

Holz

Wood / Bois



4.

Stapeln + anzünden

Stacking + lighting / Empiler + allumer




5.

Luft drosseln

Reduce air / Réduire l'air

nach
after 15 - 20 min.
après




6.

Holz nachlegen

Stoke fire with wood / Recharger le bois

 Keine Flammen
no flames / pas de flamme




ORANIER

Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois



7. Sekundärluft einstellen

Secondary air control / Ajuster l'air secondaire






8. Beenden

End / Terminer





9. Reinigung

Cleaning / Nettoyage



5568 Polar Neo 8 R II 2938156000



www.orianer.com



Videoanleitung